

KETTLER

EXE008 ERGO C6



SPECIFICATION

- Genuine ergometer with 2 user modes
- Supplied with certificate to prove the calibration as being extremely accurate
- AUTO MODE: User sets a target Watt value to train against.
- MANUAL MODE: User selects brake level and Watt value is calculated
- 10 programmes including heart rate controlled
- 4 user plus one guest memory storage
- 7 available languages pre-set into computer (EN,DE,FR,IT,NL,PL,RU)
- Induction brake system 0-400 Watts
- Flywheel mass 8KG with 8.8 rotational index = very smooth
- Pulse measurement via hand pulse sensors or chest strap (optional)
- Tablet / phone holder
- Maximum user weight 150KG
- Balanced pedals stay upright
- Transporter castors and height levellers for uneven surfaces
- Dimensions when set up 119 x 55 x 137cm
- Low access makes it easy to get on and off
- Manufactured in Germany
- 3 yr parts and labour warranty